



BROWN & GAMMONS LTD

Tel: 01462 490049 Fax: 01462 491940

www.ukmgparts.com

MGF WINDSTOP (BGF500A) FITTING INSTRUCTIONS

1. Lay down the hood fully. Undo the three screws across the plastic T-bar and pull it away over the front seats. Now the plastic T-bar is removed you will find silver T-bar mounting. At each end of the silver T-bar you will find two bolts. Using the rear/lower bolt, position the L-shape bracket into place. Repeat this at each end.

L-Shape
Bracket



Off-side

2. Once both L-shape brackets are in place, the last bracket will have to be attached. Doing this you will have to use two washers, bolt and nut. Place the bracket on the inner side of the L-shape bracket and tighten together with nut and bolt. Apply at each end.

Nearside



Assembly
layout



3. Replace the plastic T-bar cover. Now position the wind shield between the two brackets and tighten both ends with nuts provided. Once tighten position into place. Using the black covers, cover the bolts and nuts upon the wind shield brackets.



Plastic
T-Bar

